

Section 9

ANTENNA MOUNTING ACCESSORIES

Updated 08 February 2012

Antenna Bases and Cable Sets



XB

XB Base, Black, **6 mm Thread**, no cable, suit either M90T (NEXT G) or M90T (GSM) whip



OB-2

Australian Standard UHF OB Base, Black, **5/16"-26 TPI Thread**, no cable



XB4.7

XB Base, Black, **6 mm Thread**, 4.7 metres RG58 low loss stranded cable, no connector, suit either M90T (NEXT G) or M90T (GSM) whip



OB4.7

Australian Standard UHF OB Base, Black, **5/16"-26 TPI Thread**, 4.7 metres RG58 low loss stranded cable, UHF male solder connector supplied (not fitted)



CRBL

Australian Standard UHF OB Base, Black, **5/16"-26 TPI Thread**, 4.0 metres RG58 low loss stranded cable, car radio plug fitted



2323

Australian Standard UHF OB Base, White, **5/16"-26 TPI Thread**, 5 metres white RG58 stranded cable with FME Female connector fitted, FME Male to UHF Male adaptor supplied



CRBL-6

Australian Standard UHF OB Base, Black, **5/16"-26 TPI Thread**, 6.0 metres RG58 stranded cable, car radio plug fitted



OB4.7-BNC

Australian Standard UHF OB Base, Black, **5/16"-26 TPI Thread**, 4.7 metres RG58 low loss stranded cable, BNC male fitted



2204-W

Australian Standard UHF OB Base, White, **5/16"-26 TPI Thread**, 4.0 metres RG58 low loss stranded cable, car radio plug fitted



7994

Right-Angle UHF Female Base, mounts to any bracket with 17 mm minimum diameter hole



RA6.0

Right-Angle UHF Female Base, 6.0 metres RG58 low loss stranded cable, BNC male connector supplied (not fitted)



RA4.7

Right-Angle UHF Female Base, 4.7 metres RG58 low loss stranded cable, UHF male solder connector supplied (not fitted)